Mr./Mrs./Ms.:							Model:						F	Reg. No.:							
Invoice/Job No.:						Odometer Reading:						_ \	V.I.N.:								
Service type:	0	Α	0	В	0	Α	0	В	0	Α	0	В	0	Α	0	В	0	Α	0	В	i
Months: ,000 km:	6 13	12 26	18 39	24 52	30 65	36 78	42 91	48 104	54 117	60 130	66 143	72 156	78 169	84 182	90 195	96 208	102 221	108 234	114 247	120 260	1

Check - After the checking procedure, cleaning, adjusting, repairing or replacing is subject to extra labour and material cost.



DISCOVERY 4 / LR4

(3.0 TDV6 MODELS TO 11MY REST OF WORLD) MAINTENANCE CHECK SHEET

	Oil	OIL SERVICE
1.		Renew engine oil and filter (Every 6 months / 13,000 km)
2.		Renew fuel filter element (Every 6 months / 13,000 km) - Chinese and Indian markets only
3.		Check battery condition and check/top-up battery electrolyte level (Every 6 months / 13,000 km) - MENA markets only
	A B	MAIN SERVICE (VEHICLE INTERIOR)
4. 5.		Check condition and security of seats and seatbelts Check operation of all lamps, horns and warning indicators
6.		Check operation of front/rear wipers and washers and condition of wiper blades
7. 8.		Select the LOW range gears and drive the vehicle 3 to 4 vehicle lengths then re-select HIGH range gears Replace pollen filter
0.		MAIN SERVICE (VEHICLE EXTERIOR)
9.		Annual corrosion/cosmetic inspection - using annual corrosion inspection sheet
10.		Check tyre pressures, condition and tread depth
11. 12. 13.		Remove road wheels Inspect brake pads for wear, calipers for leaks and disks for condition Replace brake fluid (<i>Every 3 years</i>)*
14. 15.		Renew fuel filter element Renew fuel filter element - Chinese and Indian markets only
16.	HH	Drain fuel sedimentor

Refit road wheels to opposite sides of the same axle (Use anti-seize

Apply lubricant to door seals - Nordic markets only

Check condition of removable towbar MAIN SERVICE (UNDER BONNET)

Check condition of ancillary driving belts

260k Renew ancillary driving belt (Every 10 years)

Renew automatic transmission oil and filter 130k Renew transfer box oil, replace drain and fill plugs and washers

Renew front and rear axle oil (Every 10 years)

Check anti-freeze specific gravity

Renew coolant (Every 10 years)

B MAIN SERVICE (UNDER VEHICLE)

Renew engine oil and filter

Renew air cleaner element

(Every 7 years)

compound on spigot bore) Not vehicles fitted with uni-directional tyres Check operation of door checks, bonnet catch & fuel flap and lubricate door

Renew front and rear camshaft timing belts, tensioners and tensioner bolt

Check/top-up brake and PAS fluid levels and screen washer reservoirs

Check/top-up battery electrolyte level - low maintenance battery fitted

Adjust/Lubricate/Replace - Labour cost included in scheduled time except items marked *

17.

18.

19.

20.

21.

22.

23.

24.

25.

26.

27.

28.

29.

30.

31.

182k

234k

checks

A B MAIN SERVICE (UNDER VEHICLE)
 33. [30k] 260k Renew locking differential oil 34. Check for free play in all suspension and body mounting rubbers 35. Check condition of all suspension, driveshafts and steering boots and gaiters 36. Replace all flexible brake hoses (<i>Every 6 years</i>)* 37. Check visually brake servo hose, brake, fuel and PAS pipes, unions and electrical harnesses for chafing, leaks and corrosion 38. Adjust the electric park brake shoes 39. Check for fluid leaks 40. Check exhaust system for leaks, security and damage 41. Check steering rod ball joint fixings and condition of ball joints and dust covers If fault lamp(s) are illuminated, interrogate that system using IDS\SDD and
42. report findings* 43. Carry out road test (see WARNING over page) 44. Reset service interval announcement indicator 45. Endorse service record
46. Reset oil level indicator 47. Check for any applicable outstanding service actions or recalls 48. Report any unusual features of vehicle condition and additional work required
The maintenance items listed, are those recommended for vehicles operating under normal driving, road and climatic conditions. More frequent attention may be necessary if the vehicle is subject to stop/start operation, extremes of temperature, dusty conditions, off road driving or frequent towing of trailers. Service check completed, cosmetic/corrosion inspection check completed and service portfolio book endorsed.

Name: Signature: Date: Date:

1/12/2011 JLR 14 69 21 3E WARNING: Two wheel roller tests must not be carried out. Four wheel roller tests must be limited to 5 km/hour (3 miles/hour).

IMPORTANT - OIL CHANGE DIESEL ENGINES

If the vehicle is operated on fuel with a high sulphur content (over 0.7) the oil change intervals must not exceed 6,500Km (4000 miles)

If the vehicle is operated on fuel with a moderate sulphur content (between 0.3 - 0.7) the oil change intervals must not exceed 13.000Km (8000 miles)

IT IS RECOMMENDED THAT:

Comments/Remedial Work

After 80 km continuous use in severe off road conditions - wading, deep mud and abrasive grit/slurry - the electric park brake should be inspected, cleaned and adjusted, and the ancillary drive belt should be inspected and cleaned.

Air suspension vehicles used extensively in arduous/ off road conditions will require the compressor inlet filter to be replaced at more regular intervals.

When the vehicle is used in dusty or field conditions or deep wading, frequent attention to the air cleaner may be required.

When the vehicle is used in areas where fuel quality is poor, more frequent draining of the fuel filter/ sedimentor may be required.

For full details regarding the operations contained in this maintenance check sheet, please refer to the workshop manual.

GLOSSARY:

OIL SERVICE = The oil service is applicable to all vehicles. It is carried out at 6 month or 13,000 km intervals, whichever occurs first.

MAIN SERVICE = The main service is applicable to all vehicles. It is carried out at 12 month or 26,000 km intervals, whichever occurs first.

Main Service "A" is applicable at 12 months/26,000 km, 36 months/78,000 km, 60 months/130,000 km 84 months/182,000 km and so on.

Main Service "B" is applicable at 24 months/52,000 km, 48 months/104,000 km, 72 months/156,000 km, 96 months/208,000 km and so on. Some items do not need to be carried out at every main service and these items are identified by an indicator in the tick box e.g. 60k (This indicates that this item is only applicable every 60,000 km)

NOTE: The service required should be at the time or distance stated, which ever occurs first.